Amazon Alexa User and Installation Manual

Presenting the all new Hitachi air conditioners which are connected to the internet and can be controlled using your Amazon Alexa.

Supported Models


Please refer the service manual for the models supporting IOT connectivity and Smart Speaker.

Setup the airCloud Home Application

If you still haven't configured the airCloud Home on your mobile, please download the airCloud Home Application from Google Play Store Store and Apple Store and follow the procedure to install and setup.

Overview of connection image of air conditioner and Amazon Alexa.

airCloud Home with Smart Speaker (Alexa)



^{*}Compatibility varies depending on air conditioner models. The installation of an air Cloud Adapter might be required (available as an accessory)

Setup Your Amazon Alexa Smart Speaker

Please refer Setup Your Alexa Device to setup your Amazon Echo Device.

Supported Countries

"airCloud Home" skill is currently available for following English speaking countries in Alexa Skill Stores.

- Australia
- Canada
- UK
- India
- US

Users from other countries can create an account in US amazon and can download/use the skill by using above link for US.

How to use Alexa for your Air Conditioner?

There are two ways you can operate your Air Conditioner using Alexa:

1. First way is to, open the communication session with Alexa by saying: "Alexa, open airCloud".


If you have given specific name called "living room" to your Air Conditioner in your airCloud Home App. Then say,

- "Turn ON living room"
- "Switch ON living room"
- "Turn ON living room in cool mode"
- Second way is first to use phrase "Alexa, ask/open airCloud to" and give specific commands like, If you have given specific name called "living room" to your Air Conditioner in your airCloud Home App. Then say,
 - "Alexa, ask/open airCloud to Turn ON living room"
 - "Alexa, ask/open airCloud to Switch ON living room"
 - "Alexa, ask/open airCloud to Turn ON living room in cool mode"


Note:


• For more information on how to operate Alexa please visit <u>Help</u>.

1. Open your Amazon Alexa App, navigate to Menu and select "Skills & Games"




2. Browse or enter search keywords "airCloud Home", and select it.







3. Enable the "airCloud Home" skills.



4. Follow the on-screen instructions and login airCloud Home App Account. Please ensure that you use your email address and password that you login airCloud Home App with.




5. You have now successfully linked your airCloud Home App to "airCloud Home" Skill.



Alexa Smart Speaker (Conversation Flow Examples)

Switch on /off



Set AC mode



Set AC Temperature




Adjust AC Temperature



Check AC operation status



Set AC Fan speed



Set AC swing

